



On the “Configuration” screen of Pi-Star, scroll down to the “General Configuration” section. Set the “Radio/Modem Type” to “ZumSpot - USB Stick”. Next, click “Apply Changes”.



Next, scroll up to select “Power”



Next, select "Reboot"

